

RoadCraft Safety Products Limited

1 Knightcott Industrial Estate • Banwell • Weston Super Mare • North Somerset • BS24 6JN

Telephone: 01934 825850 • Fax: 01934 823106

WEB www.roadstuds.co.uk EMAIL sales@roadcraft.co.uk



Product Description:

- Hotline is an easy to apply, preformed thermoplastic Road Marking material. It is available in a range of colours as 5m rolls, (50 – 200 mm widths), 1m long strips and or as Numbers, Letters, Logos or Symbols precut from sheets.
- Ideal for fast permanent installation or re-instatement of road markings, car park markings and cycleways. Also used for logos, symbols, letters and numbers.
- Requires only one person and a gas torch.
- Extremely flexible.

Preparation Of Road Surface:

- Surface should be sound and in good condition.
- The surface must be clean. Brush away all loose material.
- Remove any grease or oil from the surface.
- The surface must be dry. Use the gas torch to heat until there is no further colour change, which occurs at the surface during the drying process.
- Do not apply on top of paint unless a Primer has been applied.
- On concrete and extremely smooth surfaces a Primer must be applied.
- Before applying Hotline, allow the Primer to dry fully.

Weather Conditions:

- Air temperature should be 5 °C and above.
- When applying Hotline in cold weather conditions (less than 10 °C), it is advantageous to warm the material to maximise hand ability.
- In cold weather conditions, preheat the surface well before application.

Equipment Required:

- Propane burner with regulator.
- Brush
- Primer (as necessary, dependent on type of surface).

Health & Safety Aspects:

- Wear leather safety shoes, long trousers/jacket or coveralls, high visibility vest and safety goggles.

Storage:

- Store packages flat.
- Keep materials dry, clean and avoid impact.
- Storage temperature range 5 ° to 30 °C.

Hotline Application:

- Handle all markings with care. Read the instructions carefully.
- For lining applications or small areas, pre-heat the surface with the gas torch.
- Lay out the Hotline material on the surface with glossy side up and strip away the clear protective plastic film.
- Position the marking. For larger area logos and symbols ensure there are no gaps between the edges of the pieces.
- Regulate the torch to give a medium flame.
- Hold the torch approx.150mm above the Hotline and move in a side to side motion across the material in order to initially locate the material to the surface.
- Regulate the torch to give a stronger flame.
- Hold the torch approx.150mm above the Hotline and move in a side to side motion across the material, providing even heat to fully melt the material. Apply sufficient heat to fully bond the Hotline to the substrate.
- Do not keep the flame in the same position for too long and overheat the material, as this may result in colour distortion.
- Ensure that all material, particularly the edges are fully heated and sealed to the surface.
- If initial skid resistance greater than 45 SRV is required, apply Ground Glass Granules immediately after heating the product (typically 250 g/m).
- If initial retro-reflectivity greater than 100 mcd is required, glass beads can be applied to the surface immediately after heating the product (typically 300 g/m glass beads or glass bead /aggregate).
- Water may be applied to the surface to aid cooling, if necessary.

Inspection:

- When the Hotline has cooled, check the adhesion. Attempt to lift the edge at various points around the material using an appropriate tool, e.g. blade or chisel. Use additional heat if area of low adhesion is detected.
- Hotline can be trafficked within minutes of application.
- Visually check for surface dressing embedment and coverage rate.

For further information you can contact us at:

Roadcraft Safety Products Ltd
Unit 1, Knightcott Ind Estate
Banwell
Weston Super Mare
North Somerset Bs29 6JN
Tel: 01934 825850 Fax: 01934 823106
Web:www.roadcraft.com Email Sales@roadcraft.com

